



Title of Document:	HANDLING MANUAL	Issue No. CHM-1-2513	Rev. 1
Customer:	GENERAL	Issue date: December 27, 2013	
Title subject:	JFPS Connector (Tin Plating Type)	Revision date: April 24, 2020	

This handling manual describes the operation points of crimping and handling of the JFPS connector (tin plating type).

C O N T E N T S

	Page
1. Product Name and Model Number.....	2
2. Storage	2
2-1 Storing the connectors	2
2-2 Storing the crimped contacts.....	2
3. Applicable Wire.....	2
4. Crimping Tool	2
5. Crimping Operation	3
5-1 Wire strip length.....	3
5-2 Oil application to the contact in crimping	3
5-3 Crimping	4
5-3-1 Measurement of the crimp height	4
5-3-2 Tensile strength of the crimp part	5
5-3-3 Crimping appearance.....	6
5-4 Precautions for the handling of the crimped contact.....	7
6. Harness Assembly Operation.....	7
6-1 Before inserting the crimped contact into the housing	7
6-1 Inserting the contact into the housing	8
6-2 How to extract the crimped contact from the housing in case of mis-insertion	8
7. Header	10
8. Check Points of Crimping Operation and Harness Assembly	10
9. Handling Precautions	11

Prepared by: <i>K. Sakamoto</i>	Checked by: <i>T. Sawano</i>	Reviewed by: <i>M. Arai</i>	Approved by: <i>T. Imazeki</i>
------------------------------------	---------------------------------	--------------------------------	-----------------------------------

JST	Title subject: JFPS Connector (Tin Plating Type)	No. CHM-1-2513
------------	--	----------------

1. Part Name and Model Number

Part name		Model No.
Receptacle contact	L type	SJFPS-81T-M1.0
Receptacle housing	X keying (Blue)	JFPSRS-01WGT-EX
		JFPSRS-*V-EX
	Y keying (black)	JFPSRS-01WGT-KY
		JFPSRS-*V-KY
	Z keying (green)	JFPSRS-01WGT-MZ
Top entry type header (With one lead)	X keying (blue)	BC*B-JFPSE-TXS
	Y keying (Black)	BC*B-JFPSK-TYS
Top entry type header (With two leads)	X keying (blue)	BC*B-JFPSE-TX
	Y keying (Black)	BC*B-JFPSK-TY
	Z keying (green)	BC01B-JFPSM-TZ

Note₁: An asterisk denotes the 2-digit circuit number. e.g. 2-circuit receptacle housing: JFPSRS-02V-EX

2. Storage

2-1 Storing the connectors

Recommended storage condition: Temperature: 5 – 35 °C, Relative humidity 60 % or less
(Under packaging like the state of JST shipment)

Keep off direct sunlight, places exposing to such corrosive gas as industrial gas (generate from a stove and whatnot) and ammonia gas (generate from a toilet and whatnot) and dusty place.

Especially, note that the seal ring and the seal rubber plate exposed to direct sunshine brings about deterioration of the rubber and adhesion of dust, affecting the waterproof performance. Also, keep the storage room from condensation.

Note that the resin molding part may break due to transportation and handling, such as processing and mating, under dry or low temperature condition.

After unpacking, return the products in the original package to store.

2-2 Storing the crimped contacts

Not leaving the crimped contact to stand in a place exposed to high humidity and direct sunshine, and not placing them directly on the ground. Keep them in a clean storage room.

3. Applicable Wire

Contact	SJFPS-81T-M1.0
Wire size	AWG#12 - #10
Wire insulation outer diameter (mm)	φ 4.0 - 5.3mm
Conductor	Annealed copper stranded wire with tin plating

Note₂: Special wires such as bare one, solid one, tin-coated one and shielding one other than the above wires cannot be used in principle.

4. Crimping Tool

Contact	SJFPS-81T-M1.0
Crimping press	AP-K2()
Applicator	MKS-L
Dies	MK/SJFPS-81-10
Applicator with dies	APLMK SJFPS81-10

Note₃: When crimping operation is conducted by using other than the above applicator and die set, JST cannot guarantee the connector performance.


5. Crimping Operation

5-1 Wire strip length

Referring to the reference value of the wire strip length stated below, strip the wire.

As the wire strip length differs depending on the wire type and the crimping method, decide the best wire strip length considering the processing condition. When a wire is stripped, do not damage or cut off the wire conductors

Reference value of wire strip length: 7.0 mm





Note₄: Do not leave such a stripped wire for a long time in order to prevent the oxidation of the conductor's surface, since such oxidation may lead to the fluctuation of the contact resistance. After stripping, complete the crimping operation as soon as possible.


5-2 Crimping

According to wires to be used, adjust the dials (the conductor part and the insulation part) of the applicator to a proper crimp height.

5-2-1 Measurement of the crimp height

Measurement of the crimp height

- A: The crimp height at the wire barrel should be set to the pre-determined dimensions.
- B: Adjust the crimp height at the wire insulation barrel as per finished outer diameter and wire type so that the wire insulation does not come off of the contact easily, and set it not to crimp excessively.
- H: Measure the crimp height at the center of the barrel using a specified micrometer.

Crimping condition at the insulation barrel


Insufficient crimping
(pressed weak)
When tension is applied
to a wire, the wire insulation
easily comes off the contact.

Good


Excessive crimping
(pressed excessively)
The barrel bites the wire too
much and may damage
the wire conductors.

Check of the crimping condition at the wire insulation barrel


Cut the insulation barrel.



Remove the wire insulation.



Check no damage.

Crimp height

SJFPS-81GG-M1.0				
Wire			Crimp height (mm)	
Style	Size	Insulation O.D. (mm)	Conductor part	Insulation part (Ref. value)
UL1015	AWG#12	φ 4.0	2.35 - 2.45	4.9
	AWG#10	φ 4.7	2.65 - 2.75	5.0

Note₅: The crimp height of the insulation part is the reference value.

It depends on the wire insulation's outer diameter and its material, so set the crimp height of the insulation part in crimping following the confirmation method.

JST	Title subject: JFPS Connector (Tin Plating Type)	No. CHM-1-2513
------------	--	----------------

5-2-2 Tensile strength at the crimped part

After adjusting the crimp height, check the tensile strength using the test samples.

In case the tensile strength greatly differs from the normal tensile strength (actual value), check if there is a defect. The tensile strength may be different even in the same wire size due to the difference in strength of wire itself.


Table of the tensile strength at the crimped part

SJFPS-81T-M1.0			
Wire		Actual value (N)	Requirement (N min.)
Style	Size		
UL1015	AWG#12	770 – 830	300
	AWG#10	890 - 970	400



Note₆: The actual value shows the tensile strength at the crimper part of the sample with the conductor part only crimped.

5-2-3 Crimping appearance

Check the crimping appearance visually for correct crimping with equipment such as a loupe.


Part name of crimped contact

Deviation of insulation barrel




Item	Reference value
Bending up	5° max.
Bending down	4° max.
Twisting	5° max.
Rolling	5° max.
Bell-mouth (wire side)	0.15 ~ 0.65 mm
Cut-off length	0.5 mm max.
Protruded wire conductor length	0.5 ~ 1.2 mm
Seam at wire barrel	Seam should be closed.
Deviation of insulation barrel	0.5 mm max.


Note₇: Bending up/down, twisting and rolling
 Note that bending up/down, twisting and rolling may lead to deteriorating the contact insertion in the housing, lowering the contact retention force or poor mating.

Example of defective crimping


Long protruded wire brush




Short protruded wire brush




Stray wire conductor



Bitten wire insulation with wire barrel



Protrusion of wire insulation



There should be no outstanding burr, or a burr at only one end should not be seen.

5-3 Precautions for the handling of the crimped contact

As the crimped contact before inserting into the housing is subject to the deformation, etc. by external forces, pay careful attention to the following 3 points for the storage and the handling:

- ① The number of the crimped contacts for one bundle should be 50 pcs. max. Protect the contacts by wrapping with paper to prevent from the deformation and adhesion of foreign substances, and keep them in an adequate box.
- ② Do not stack too much quantity of the crimped contacts nor place anything on them, because the weight of themselves may cause the deformation of the contact and troubles such as poor contact.
- ③ Fasten the tip of the remaining chain contact in the reel with a wire or a string to the reel so as not to unravel, put the reel in a carton box and store it in a clean room at a room temperature.

6. Harness Assembly Operation

The harness assembly operation is a very important process for the connector performance and the harness quality. Careful operation is required for the harness assembly.


6-1 Before inserting the crimped contact into the housing

- ① Do not place other things on or near working table and do not conduct any other works on the same working table to prevent from operation mistakes.
- ② Do not use improperly crimped or deformed contacts (including the contact lance and the mating part).

6-2 Inserting the contact into the housing

- ① Insert the contact into the housing, paying attention to the direction, because they have direction. Have the locking lever of the receptacle housing and the barrel seam part of the contact turn up when inserting.
- ② When the contact is inserted into the proper position, there is a good fit with an audible click.
- ③ Do not insert such an insertion jig as a pin in place of the contact, because the tip of the pin accidentally reaches the mating part, resulting in poor contact and contact deformation.
- ④ Check per each insertion that there is backlash in the mating direction and that the contact is securely locked by pulling a wire softly (about 10N) in order to confirm that the contact does not come off the housing.
Do not pull the wires too much, because the contact may come off the housing due to the deformation of the lance.

In order to avoid the mating error with the header side, 2 kinds of the housings that have no compatibility are used. For the identification, check the key mark, the key slot (circled in the figure below) and the color as shown below. Also, do the harness processing free from wiring error according to the drawing on which the harness specification is shown.



6-3 How to extract the crimped contact from the housing in case of mis-insertion

When the crimped contact is inserted into an improper circuit hole, conduct the following points:

- ① Do not reuse the housing and contact that have been inserted in an improper circuit once but use new ones. (It is shown below how the contact is extracted from the housing.)
 - ② When the contact that has been inserted in an improper circuit is extracted from the housing and reused.
 - Only specified person conducts the operation.
 - In case the contact and the housing are reused, the reuse should be once. From twice, use a new contact and housing.
 - Carefully check that the extracted contact and housing lance are free from damage, deformation or fatigue, and then, reuse it. When found, replace it with the new ones.
 - After the modification completes, be sure to check that the crimped contact is securely inserted according to the item 6-2 ④.
- When the contact comes off the housing, use the new housing.




How to extract the crimped contact from the housing

- ① Prepare the contact extraction jig (EJ-JFPSR)..
- ② Insert the jig straightly between the contact and the housing lance from the mating direction.
(Refer to the figure at the right side.)
- ③ Insert the jig into the innermost of the housing and raise the housing lance.
- ④ Pull the wire out softly with a force of approx. 10N max. with raising the housing lance by the jig and extract the crimped contact from the housing.



When the contact cannot be extracted even by pulling the wire softly, do not pull it by force, and try again back to step ②.

Use the extraction jig for this connector. The use of other than the dedicated jig may bring the contact and the housing to the deformation.

The positions to insert the extraction jig



The housing lance is raised.



JST	Title subject: JFPS Connector (Tin Plating Type)	No. CHM-1-2513
------------	--	----------------

7. Header

① Floating from PC board

The header of JFPS connector has a mechanism to prevent from coming off PC board when inserting. However, when the header floats by external force or vibration, push the header softly to cohere the bottom of the header to the surface of PC board, and then, solder it.

② Flux

Use rosin type flux.

As inorganic flux may corrode the wafer, do not use it.

③ Dipping soldering

Conduct soldering operation in a temperature range of 245°C - 260°C and within 5 - 10 seconds.

④ Soldering by hand and soldering repair

When soldering by using a soldering iron or soldering repair for bridge are conducted, note the following points, because the header resin may deteriorate due to heating.

Temperature of soldering iron: 350 °C

Soldering time: Solder the connector quickly within 3 seconds.

Soldering method: Do not apply external force by such an operation as pushing the header post with the tip of a soldering iron during soldering.

⑤ Cleaning operation

JFPS connector (tin plating) is not been influenced with cleaning solvent for normal flux cleaning.

When cleaning solvent contaminated by flux remained on the header, however, poor contact or other defects may be caused.

8. Check Points of Crimping Operation and Harness Assembly

The operations of crimping and assembly affect the reliability of the connector.

It is recommended that crimping and assembly operations and the finished products be controlled concentrating upon the following check points:

Process	Check point	Description
Crimping	Appearance	① Check that wires are crimped at the normal position. ② Check that the crimped configuration is normal and excessive burr does not appear. ③ Check that uncrimped wires are not left behind. ④ Check that the contact is not bent, deflected or deformed. ⑤ Check that the contact is free from dirt, scratches, stains or discoloration.
	Crimp height	① Check that the crimp height is adequate.
	Tensile strength	① Check that the tensile strength are adequate.
Harness assembly	Appearance	① Check that the contact is properly inserted into the housing. ② Check that the contact is securely locked with the housing. ③ Check miss-wiring. ④ Check that the housing is free from dirt and foreign matters.
Finished product (Harness)	Appearance	① Follow all descriptions stated above in "Appearance."

JST	Title subject: JFPS Connector (Tin Plating Type)	No. CHM-1-2513
------------	--	----------------

9. Handling Precautions

- ① Careful operation is required for the storage and the transportation of the housing and the harness in a stacking condition to prevent the housing from the deformation.
Stacking allowance in the storage and the transportation are up to 5 stacks of the carton box for the housing, and store and transport the harness product with as little load as possible.
- ② Do not mate the header and the receptacle contact without inserting it into the housing, because the contacting part may be deformed.
- ③ When electrical continuity test for the harness is conducted, use the counterpart of the connector.
Never use the different type pin like a tester pin, because the contacting part may be deformed.
 - Check that the testing connector for continuity inspection is free from deformation, damage and stains.
When they are found, replace with a new one.
Periodically replace the testing connector.
 - Mate and unmate the connector with care, holding the housing not to pry.
When the inspection board is used, design it considering that the mating and unmating works are not difficult.
- ④ Never spray fumy insecticide in the place where the connector and the harnessed product are stored, or the harness operation is conducted, because such spray may rust the metal part.
- ⑤ Do not contaminate the contact with household goods such as oils, detergent, seasoning, fruit juice and insecticide. If contaminated, do not use.
- ⑥ In mating and unmating the connector, do the operation straightly on the mating axis not to pry, because the contact may be deformed or the connector may be damaged.
- ⑦ In handling the wires, keep an enough length or fix the wire not to apply other than an external load of the wire buckling level to the contact.

Handling wires

A load applies to the contact because the bending position is close to the housing.

